

2010-2011 Cubby Mount Installation Instructions

Step 1.

Slide 17mm ball attachment on to the cubby mount



Step 3.

With adhesive exposed, apply cubby mount to the underside of the compartment door as shown



Step 2.

Remove backing on velcro to expose adhesive



Step 4.

Once velcro is apply, wait 30 mins before gently removing the cubby mount. At this time, attach accessories per Arkon's instructions



www.subarucubbymount.com is not responsible for any damages caused to your car, your device or yourself due to the installation or use of this mounting solution.